

warranty

Amalgamated Appliances (Pty) Limited ("the Supplier") warrants to the original purchaser of this product ("the Customer") that this product will be free of defects in material and workmanship which under normal, personal, family or household purpose manifest themselves within a period of 365 days from the date of purchase or in respect of commercial or professional purposes, manifest themselves within a period of 90 days from the date of purchase. Any claim in terms of the warranty must be supported by a proof of purchase. If such proof is not available, then notwithstanding anything to the contrary herein, the Supplier's normal charge for service and /or spares will be payable by the Customer upon collection of the repaired product. If a claim is made in terms of the aforesaid warranty within the first 7 days from the date of purchase, the faulty product will be exchanged (provided that the product is in its original packaging with all accessories). Failing return of the product within 7 days, the Supplier's liability shall be limited on return to the Supplier of the product or parts thereof, to the replacement or repair (in the sole discretion of the supplier, or its duly authorised service dealer) of the product to eliminate any defect in workmanship or materials found to be due exclusively to any acts or omissions on the parts of the Suppliers, of which defects the Supplier shall have been notified in writing by the Customer within the aforesaid warranty period. The warranty provided herein and the obligations of the Supplier as aforesaid are in lieu of, and the Customer waives, all other warranties, guarantees, conditions or liabilities, express or implied, arising by law or otherwise, including without limitation, any obligation of the Supplier in respect of any injury, loss or damage (direct, indirect or consequential) arising out of the use of, or inability to use, this product and whether or not occasioned by the Supplier's negligence (gross or otherwise) or any act or omission on its part. The warranty does not include and will not be construed to cover products damaged as a result of disaster, misuse, abuse or any non-authorized modification of the product. The warranty does not include replacement of light bulbs, heater bars, paper bags or any glass, plastic bowl or jug or other expendables. During the warranty period the product should be taken to a service centre of the Supplier or one of its duly authorised service agents. The Supplier neither assumes nor authorises any other person to assume for it, any additional liability in connection with the sale or servicing of its products.

AMALGAMATED APPLIANCES (PTY) LTD.

29, HERONMERE ROAD
BOOYSENS, JOHANNESBURG
2016

P O BOX 39186
BOOYSENS

2016

JOHANNESBURG TEL NO. (011) 490 9000
FAX NO. (011) 490 9399

CAPE TOWN TEL NO. (021) 535-0600
DURBAN TEL NO. (031) 792-6000

Win prizes on line: www.russellhobbs.co.za

5



Russell Hobbs

kudos range



2-slice toaster

instructions and guarantee

76-8719-5

Read these instructions before use and keep them safe. If you pass the toaster on, pass on the instructions too. Remove all packaging, but keep it till you're satisfied the toaster is working.

important safeguards

Follow basic safety precautions, including:

1. Don't put your toaster in water or any other liquid, don't use it in a bathroom, near water, or outdoors.
2. The toaster should only be used by or under the supervision of a responsible adult.
3. Position the toaster upright on a stable, level, heat-resistant surface, near a power socket and out of reach of children.
4. Don't use it near or below curtains or other combustible materials and watch it, as bread can catch fire if overcooked.
5. The area round the toasting slots will get hot during use – don't touch!
6. Route the cable so it doesn't overhang and can't be caught accidentally. Wind excess cable round the cord storage clips underneath the toaster.
7. When using only one toasting slot, don't let anything get into the other slot. Both slots will become "live" when you lower the bread carriage handle.
8. Don't let the toasting slots become covered during toasting, or while hot.
9. If bread gets jammed, unplug the toaster, let it cool, and carefully remove the bread. Don't use anything sharp – you'll damage the elements.
10. Don't toast buttered items or make toasted sandwiches in the toaster.
11. Don't use torn, curled up, or misshapen slices, you may jam the toaster.
12. Unplug after use, and let it cool down before cleaning and storing away.
13. Clean the crumb tray frequently, to avoid a build up of crumbs. This is unhygienic and could cause a fire hazard.
14. Don't use the toaster unless the crumb tray is in place and closed.
15. Keep the toaster and cable away from hotplates, hobs and burners.
16. Don't use the toaster if it's damaged or malfunctions. If the cable is damaged, the toaster must be returned, in order to avoid hazard.

household use only

before using for the first time

Set the browning indicator to 6, and operate the toaster without bread, to cure the new elements. This may smell a bit, but it's nothing to worry about. Ensure the room is well ventilated.

making toast

1. Put the toaster upright on a table, level, heat resistant surface, clear of curtains and other combustible materials. Don't put it on or near anything that could be damaged even by moderate sources of heat.
2. Plug it into a power socket and, if necessary, switch the socket on. The browning indicator will show 3.
3. Use the buttons to increase or decrease the setting. The range available is 1 (light) to 6 (dark). Keep pressing to "fast forward".
4. Put bread centrally into the toasting slots (maximum thickness 28mm/1 1/8").

2



electric
shock risk

5. Press the bread carriage handle down fully – it won't lock down unless the toaster is connected to the electricity supply.

6. The button will light up, and your toast will start cooking.

7. When it's done, the toaster will switch itself off, and the toast will pop up.

frozen

Set the browning indicator to your normal setting, put the frozen bread into the slot(s), lower the bread carriage handle, then press the button. The button will light up, and toasting time will be adjusted automatically to give the same degree of browning you get with unfrozen bread.

cancel

To stop the toaster before it's finished, press the button.

reheating toast

Use a lower setting, and only reheat plain, unbuttered toast.

extra lift

To make it easier to remove smaller items, like crumpets and muffins, you can raise the bread carriage handle an extra 2cm.

hints and tips

If toasting two slices, they should be of similar size, thickness and freshness. Old (yesterday's) bread contains less moisture, so makes crisper toast. Old or thin bread cooks faster than fresh or thick bread, so use a lower setting. Sweet bread products (tea cakes, fruit loaf, etc.) brown much more quickly than ordinary bread, so should be toasted on a lighter setting.

care and maintenance


First – unplug the toaster and let it cool down fully.

Wipe the outside with a soft damp cloth.

Don't let anything enter the slots, as this might damage the elements.

Don't use harsh or abrasive cleaning agents or solvents.

Don't put the toaster in water or any other liquid.



3

crumbs

Remove crumbs frequently, they're unhygienic, and could cause a fire hazard. Unplug the toaster and let it cool down fully. Pull the crumb tray out and empty it. Wipe it with a damp cloth, dry it, then slide it back into the toaster. Don't use the toaster unless the crumb tray is in place and closed.

changing the fitted/molded plug


Should the need arise to change the fitted/molded plug follow these instructions:

Mains (AC) Operation

This unit is designed to operate on 230V- 240V current only. Connecting to other power sources may damage the unit.

Connect three-pin plug as follows:

The wires in this mains lead are coloured in accordance with the following code: Green/Yellow = Earth Blue = Neutral Brown = Live



service

There are no user serviceable parts in this appliance. If the appliance is not operating correctly, please check that:

1. You have followed the instructions correctly.
2. Has the unit been wired correctly, and is the wall socket switched on.
3. Are the mains power supply On.

If the appliance still does not work:

In the first instance, consult your retailer for possible repair or replacement. If your retailer fails to solve your problem and you need to return the appliance, make sure that:

1. The unit is packed carefully back into its original packaging.
2. Proof of purchase is attached.
3. Give the reason why you are returning it.

If the supply cord is damaged, it must be replaced by the manufacturer or its service agents in order to avoid a hazard. If service becomes necessary within the warranty period the appliance should be returned to an approved Amalgamated Appliances (Pty) Ltd service centre. Servicing outside the warranty period is still available, however it will be chargeable.

Please affix your proof of purchase/receipt here.
in the event of a claim under warranty, this receipt must
be produced.

4