



# Russell Hobbs

## WARRANTY AND INSTRUCTIONS



**MODEL NO. 10969**

**RUSSELL HOBBS SATIN QUARTZ 3 TIER FOOD STEAMER**

Congratulations on purchasing our Russell Hobbs Satin Quartz 3 tier Food Steamer. Each unit is manufactured to ensure safety and reliability. Before using this appliance for the first time, please read the instruction manual carefully and keep it for future reference.

#### **FEATURES OF THE RUSSELL HOBBS 3 TIER STAINLESS STEEL FOOD STEAMER:**

- 3 Baskets each with 3 litre food capacity Separate rice bowl
- Digital display with 120 minute countdown timer
- Baskets stack into each other for easy storage
- Safe and easy water top-up feature whilst steaming
- Recipes included
- For domestic use only
- 2 year warranty (1 year retail • 1 year extended upon online registration of product • visit [www.russellhobbs.co.za](http://www.russellhobbs.co.za))

#### **IMPORTANT SAFEGUARDS**

When using any electrical appliance, basic safety precautions should always be followed including the following:


1. Please read the instructions carefully before using any appliance.
2. Always ensure that the voltage on the rating label corresponds to the mains voltage in your home.
3. Incorrect operation and improper use can damage the appliance and cause injury to the user.
4. The appliance is intended for household use only. Commercial use invalids the warranty and the supplier cannot be held responsible for injury or damage caused when using the appliance for any other purpose than that intended.
5. Avoid any contact with moving parts.
6. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
7. Children should be supervised to ensure that they do not play with the appliance.
8. Check the power cord and plug regularly for any damage. If the cord or the plug is damaged, the manufacturer or a qualified person must replace it in order to avoid an

electrical hazard. Do not use frozen food inside the steamer; food should be completely defrosted before using inside the steamer.

9. Do not touch the hot surfaces of the base unit, lid, dishes, rice bowl or diffuser.
10. Use oven gloves when removing the hot dishes, rice bowl, lid or diffuser. Lift dishes by only using the handles.
11. Don't reach over the top of the steamer. Steam will escape from the vent, baskets and base unit.
12. Keep hands, arms, face etc clear from the escaping steam when opening the lid or moving dishes.
13. Don't line the steamer with paper or foil it will block the steam holes.
14. Do not cover the steamer when in use.
15. Let the steamer cool down completely before you clean it or put it away. Never move the appliance when it is full, when switched on or before it has cooled down.
16. Do not use the steamer if it has been dropped or damaged in any way. In case of damage, take the unit in for examination and/or repair by an authorised service agent.
17. To reduce the risk of electric shock, do not immerse or expose the motor assembly, plug or the power cord to water or any other liquid.
18. Never immerse the base unit in water or any other liquid for cleaning purposes.
19. Remove the plug from the socket by gripping the plug. Do not pull on the cord to disconnect the appliance from the mains. Always unplug the unit when not in use, before cleaning or when adding or removing parts.
20. The use of accessory attachments that are not recommended or supplied by the manufacturer may result in injuries, fire or electric shock.
21. A short cord is provided to reduce the hazards resulting from becoming entangled in or tripping over a longer cord.
22. Do not let the cord hang over the edge of a table or counter. Ensure that the cord is not in a position where it can be pulled on inadvertently.
23. Do not allow the cord to touch hot surfaces and do not place on or near a hot gas or electric burner or in a heated oven.
24. Do not use the appliance on a gas or electric cooking top or over or near an open flame.
25. Use of an extension cord with the appliance is not recommended. However, if it is necessary to use an extension lead, ensure that the lead is suited to the power consumption of the appliance to avoid overheating of the extension cord, appliance or plug point. Do not place the extension cord in a position where it can be pulled on by children or animals, or tripped over.

26. This appliance is not suitable for outdoor use. Do not use this appliance for anything other than its intended use.
27. DO NOT carry the appliance by the power cord.
28. Do not leave the appliance unattended during use. Always unplug the unit when not in use or before cleaning.
29. Always operate the appliance on a smooth, even, stable surface. Do not place the unit on a hot surface.
30. Ensure that the switch is in the "Off" position after each use.
31. The manufacturer does not accept responsibility for any damage or injury caused by improper or incorrect use, or for repairs carried out by unauthorised personnel.
32. In case of technical problems, switch off the machine and do not attempt to repair it yourself. Return the appliance to an authorised service facility for examination, adjustment or repair. Always insist on the use of original spare parts. Failure to comply with the above mentioned pre-cautions and instructions, could affect the safe operation of this machine.

## PARTS DIAGRAM



## **OPERATING INSTRUCTIONS**

Check that the voltage of the appliance corresponds to the mains voltage of your home. Remove all packaging from the **INSIDE** and **OUTSIDE** and be sure you understand the controls on your food steamer. Wash the diffuser, dishes, rice bowl, and lid in warm soapy water, rinse well and dry thoroughly before first use. Give the base a wipe with a warm cloth.

## **PREPARATION**

1. Put the base unit on a firm, level, heat-resistant surface, close to a power socket, and out of the reach of children.
2. Steam will escape, so don't put it near curtains, under shelves or cupboards, or near anything that might be damaged by the escaping steam.
3. Have dinner plates or a tray handy to put the baskets on afterwards, as they will drip. This would be a good time to set out serving spoons, tongs, etc., for emptying the baskets. Don't forget the oven gloves.
4. Check that the filter is in place inside the steamer

## **FILL THE WATER RESERVOIR**

5. Fill the reservoir to the **MAX** mark. This will give you about 60 minutes steaming, enough time for most foods.
6. Should the need arise to top up the reservoir before the steam cycle is completed, use a thumb to pull the top of the filler out till it clicks into place- it opens about a centimetre.
7. Push the top of the filler back into place on the side of the steamer.

**PLEASE NOTE:** It takes a few minutes for the water to trickle into the water reservoir, so this process will need to be repeated a number of times in order to increase the water level.

8. Don't add anything to the water. Seasonings, marinades etc, should be added to the food, not the steaming water. They won't circulate with the steam, they will just concentrate in the reservoir, possibly damaging the surfaces of the reservoir and element.

## **FIT THE DIFFUSER**

9. The diffuser directs the steam from the steam tube through the steam holes in the bottom basket. It also prevents the heater and reservoir being overwhelmed by juices from the cooking foods.

## **ASSEMBLE THE BASKET(S)**

10. Put the diffuser on top of the reservoir, then for:
  - **1 basket:** fit the bottom basket (the smallest) on top of the diffuser, then put the food in the basket
  - **2 baskets:** put the second basket on top of the bottom basket, so the rim on its underside fits inside the wall of the bottom basket, then fill it.
  - **3 baskets:** put the third basket (the biggest) on top of the second basket so the rim on its underside fits inside the wall of the second basket, and fill it.

## **STEAM ROOM**

11. To allow the steam to circulate:
  - a. Pack food loosely in the baskets
  - b. Whenever possible, use single layers of food
  - c. Leave spaces between the pieces
  - d. When layering food in a basket, leave spaces between the pieces in each layout to let the steam circulate.

## **UNIFORMITY**

12. For uniform cooking:
  - a. Try to cut all pieces of food in a basket to roughly the same size
  - b. Put larger pieces, or food with long cooking times, furthest from the reservoir
  - c. Put smaller pieces, of food with short cooking times, furthers from the reservoir
  - d. Don't worry too much about overcooking - steaming is a relatively gentle cooking method and a few minutes extra generally won't matter.
  - e. Don't overcook fish - it will chew like rubber and taste like cardboard

**PLEASE NOTE:** Juices from the upper basket(s) will drip into the basket(s) below. Don't put delicate flavours below strong ones, or vegetables below greasy foods.

### **FIT THE LID**

13. Put the lid on top, so that its rim fits inside the wall of the topmost basket.
14. Don't try to steam without the lid in place. The food won't cook, the water won't last and you will fill the kitchen with steam.

### **PLUG IT IN**

15. Plug the base unit into the power socket (switch the socket on, if switchable).
16. The timer will beep and the display will show 00 MIN.

### **SET THE TIMER**

17. Press and release the SET button to increase the time in 5 minute steps till it shows the time you want.
18. If you go past 60 minutes, it will revert to 00.

### **START**

19. Press the 0/1 button.
20. The indicator light will come on to let you know the element is working, MIN will flash on the display and the timer will count down.
21. When the timer returns to 0, the element will switch off, the light will go out, and the timer will beep to remind you to empty the baskets.

### **EMPTYING**

22. Press the 0/1 button to cut off the beeper.
23. Unplug the base unit from the power socket.
24. Everything will be hot - use oven gloves or a cloth - use the handles.
25. Steam will escape from the baskets - keep hands, face, etc, away from the area above the steamer. Do not lean over it.
26. When you lift the lid, angle it to direct steam away from your body.
27. Put the lid on a plate or tray.
28. Lift the baskets off and set them down on plates or a tray before serving.
29. Take care when removing the diffuser - apart from being very hot, the juices are likely to stain if spilt.
30. Leave any water remaining in the reservoir to cool, then pour it out via one of the handles, to avoid getting the controls or the mains lead wet.

## **OVER 60 MINUTES?**

31. If you intend to steam for from than 60 minutes:
  - a. either keep an eye on the water level and/or the timer and top up the reservoir at about the half way mark.
  - b. or set the timer for half the steaming time, then the beep will alert you to top up the reservoir.

## **TOPPING UP**

32. To top up
  - a. Use water
  - b. Pour it slowly into the reservoir via the diffuser handles
  - c. Keep an eye on the water level indicator - don't let it get above max
  - d. Pour slowly to avoid splashing

## **BOILING DRY**

33. Don't worry - we thought of this and fitted a thermostat.
34. It's still not a good idea, as you lose control of the cooking process, but it needn't be a disaster.
35. In the event of a boil-dry occurring, the thermostat will cut off power to the element, but the light will remain on.
36. The thermostat will cycle on and off until you remember to add water, or until the timer returns to 0 and switches off.
37. Unplug the base unit, let it cool for a couple of minutes, then fill up with boiling water and start again.
38. When calculating the time needed, allow for the whole of the time already spent steaming, and part of the time between running dry and restarting, as the cooking process will not have stopped immediately the reservoir ran dry.
39. If you watch the cooking process, there's no reason why the rescue operation shouldn't be 100% successful.
40. If it isn't then a piquant sauce should do the trick - try something with lemon or lime in it first. If all else fails, ginger, garlic or chilli will hide absolutely everything.

## **EARLY STOPPING**

41. If you want to stop the cooking process for any reason, switch the socket off, and unplug the steamer.
42. Remember, everything will be hot. Use the oven gloves and take care.



## **SWAPPING THE BASKETS**

If you want to carry on steaming, but you've got something in the bottom basket and you don't want to empty it, put the base ring on top of the diffuser and sit one of the other baskets on it. The bottom of the base ring fits the diffuser and the steps inside fit the bases of the middle and top baskets.

## **THE RICE BOWL**

When cooking rice, add water to the rice bowl in addition to the water in the reservoir. The volume of water added to the rice bowl should be roughly one and a quarter times the volume of the rice. Put the rice bowl in the topmost basket. Juices from other foods will alter the flavour of the rice, and the additional liquid may make it mushy.

## **TIMING**

The times given in the cooking guide on page 12 are for a single layer of food in the bottom basket, used on its own.

Extend these times:

- a. if two or three baskets are used, as the same amount of steam is having heat a greater volume of food.
- b. if a particular food is cooked in the second or third basket. Generally speaking, the further the food is from the element, the longer it will take to cook.
- c. if food is layered within a basket.

You will need to experiment to find the times and positions which suit your favourite foods and food combinations. Fish is cooked when it appears opaque and can be flaked easily. Cook meat until the juices run clear. Leaf vegetables should be cooked as little as possible, to keep them green and crisp - plunging them into iced water will stop the cooking process.

## **CLEANING AND MAINTENANCE**

- This appliance is for household use only and is not user-serviceable.
- Do not open or change any parts by yourself. Please refer to a qualified electrical service department or return to the supplier if servicing is necessary.
- Always remember to unplug the unit from the electrical outlet when not in use and before cleaning. .
- Do not use bleach or other abrasive substance or solvents to clean your appliance as it can be damaging to the finish.
- Do not immerse the whole unit in water or any other liquid, or hold it under a running tap to clean.
- Wait until the unit is completely cool before cleaning.
- We do not recommend using a dishwasher, as this may affect the surface finish of the baskets, etc. Wipe unit, inside and out with a clean damp cloth
- To remove stubborn spots/marks, wipe the surfaces with a cloth slightly dampened in soapy water or mild non-abrasive cleaner. Rinse and dry with a clean, dry, soft cloth.

## **DESCALING**

In time scale deposits may build up on the interior surfaces of the reservoir and element. These deposits will impair the efficiency of the steamer and may shorten its working life. To descale the reservoir and element, fill the reservoir with 600ml (1pt) white vinegar, plug it into the power socket and set the timer to 20 minutes. Ensure the kitchen is well ventilated while doing this as heating the vinegar will give off an unpleasant smell. Don't fit the juice collector, baskets, rice bowl or lid. After the 20 minutes is up, leave it to cool completely, then pour out the vinegar and rinse the reservoir several times with cold water to remove all trace of the vinegar. Pour from the end of the reservoir, to prevent liquid getting to the timer at the front or the mains lead at the rear. Dry the base unit thoroughly. Don't use any liquid other than white vinegar and don't use a proprietary descaler.

## **STORING THE APPLIANCE**

- Unplug the unit from the wall outlet and clean all the parts as instructed above. Ensure that all parts are dry before storing.
- Store the appliance in its box or in a clean, dry place.
- Never store the appliance while it is still wet or dirty.
- Never wrap the power cord around the appliance.

## FOOD STEAMING TIME

### Vegetables

Artichokes	400g	40-45 mins (top up the reservoir)
Asparagus	400g	15 minutes
Beans, green	400g	18-20 minutes
Broccoli	400g	15 minutes
Brussels Sprouts	400g	15-18 minutes
Cabbage	1 head, cored and cut into eighths	20 minutes
Carrots, sliced	400g	15 minutes
Cauliflower	1 head, cored	15 minutes
Corn on the cob, fresh		15 minutes
Courgettes, sliced	400g	10 minutes
Mushrooms, fresh	200g	10-13 minutes
Peas, green, shelled	400g	12-15 minutes
Peppers, deseeded & sliced	1 whole	10 minutes
Potatoes, white, all purpose, peeled and chopped	900g	20 minutes
Potatoes, new., whole	10-12	20-25 minutes
Spinach, fresh	250g	10 minutes

---

### Meat and Poultry

Chicken breasts (boneless fillets) (depending on size and thickness)	400g	20-30 minutes
Frankfurter sausages (prick before cooking)	400g	15 minutes

### Fish and Seafood

Mussels, fresh	400g	10-15 minutes
Don't use mussels that are open prior to cooking. Steam until the shells open full. Discard any that do not open after cooking.		
Prawns, fresh	400g	6-8 minutes
Lobster tail, frozen	2 pieces	20-22 minutes
Fish fillets, fresh, 6-13mm thick, plaice, mackerel, trout etc	200g	10 minutes
Fish steaks, fresh, 19-25mm thick, salmon, cod, tuna etc	200g	12-17 minutes

---

**Rice, cereal and pasta**

White rice, 2 servings	200g with 300ml water	35-40 minutes
Brown rice, 2 servings	200g with 300ml water	45-50 minutes (top up the reservoir)
Couscous, 2 servings	150g with 300ml water	10-12 minutes
Pasta (spaghetti), 2 servings	100g with 500ml water	20 minutes

---

## RECIPES

### WHOLE FISH COOKED IN WHITE WINE AND THAI MARINADE

Whole fish (e.g. trout)	2, about 140g each or fillets
Dry white wine	2 Tbsp
Fresh ginger	1 small piece, chopped finely
Fresh garlic clove	1 chopped finely
Fresh lime	Juice and zest from half a lime
Soy sauce	2 Tbsp
Fresh red chilli	1 chopped finely
Spring onions	1 small bunch, chopped
Lemon grass	1 stick, finely chopped
Fresh coriander	1 small bunch, finely chopped

Mix all the marinade ingredients in a large bowl and add the fish. Cover the fish with the marinade to coat and stand in the fridge for 20 minutes before cooking. Steam the fish in the bottom basket for about 15 minutes till the fish is fully cooked.

---

### SALMON STEAKS WITH BASIL SAUCE AND VEGETABLE MEDLEY

Salmon steaks	4
---------------	---

#### **Basil Sauce**

Fresh basil leaves	Large bunch, roughly chopped
Lemon juice	2 Tbsp
Olive oil	1 Tbsp
Garlic	1 clove, crushed
Parmesan	25g, grated
Pine nuts	
Crème fraiche	2 Tbsp
Salt and pepper	

Vegetable medley	
Red pepper	Half, cut into strips

Yellow pepper	Half, cut into strips
Mushrooms	4-6 sliced
Baby corn	4-6 sliced lengthways
Mange tout	small handfull
Asparagus tips	6
Salt and Pepper	
Dry white wine	
Dried mixed herbs	1 tsp

Put the vegetables on a large piece of foil and add white wine, dried herbs and seasoning. Fold the foil round the vegetables to make a parcel and put it in the bottom basket. Put the salmon in the second basket (above the veg) and cook for 12-15 minutes. Meanwhile, process the sauce ingredients, warm them gently in a saucepan, then serve over the salmon and vegetables.

---

## **CHINESE MEATBALLS (Makes 10-12)**

Minced beef or pork	500g
Sesame seeds	100g
Water	2 Tbsp
Rice wine	1½ Tbsp
Corn maize	1 Tbsp
Soy sauce	1 tsp
Spring onions	1 bunch, finely chopped
Dried coriander	1 tsp
Paprika	1 tsp
Chinese mixed spice	2 tsp
Salt and pepper	

Mix the ingredients in a bowl and season well. Shape into balls, put on a plate, and cover. Refrigerate for about 20 minutes to help keep their shape, then put the meatballs in the bottom basket and cook for 25-30 minutes.

---

## **WINTER VEGETABLE LAYERS**

Broccoli	2-3 florets cut into small pieces
Carrot	1, sliced
Onion	1 small, sliced
Mushrooms	3-4 sliced
Potatoes	3 small, sliced or cubed
Celery	1 stick, sliced
Vegetable stock	200ml
Dried mixed herbs	1 tsp
Fresh mozzarella	75g sliced
Black pepper	

Layer the vegetables in a dish (separate glass/plastic dish that will fit inside the steam basket) and season with black pepper. Pour over the stock and top with mozzarella. Cover with foil and steam for 25-30 minutes.

---

## ITALIAN STYLE ASPARAGUS WITH BALSAMIC DRESSING

Fresh asparagus	500g trimmed
Pine nuts	50g
Parmesan cheese	25g grated
Salt and pepper	

### Dressing

Balsamic vinegar	2 Tbsp
Fresh garlic	1 clove, crushed
Italian tomatoes	3-4 roughly chopped
Olive oil	3-4 Tbsp
Fresh basil	large bunch, roughly chopped

Steam the asparagus in the bottom basket for about 10 minutes or till its cooked the way you like it. Meanwhile mix the dressing ingredients. Lay the asparagus on a warm plate, pour over the dressing and sprinkle with nuts and Parmesan. Season to taste and serve immediately.

---

## CHICKEN WITH CREAMY WHOLEGRAIN MUSTARD SAUCE & HERBY NEW POTATOES

Chicken fillets	4, skinless
Butter	25g
Garlic	1 clove, crushed
Shallots	2, finely chopped
Wholegrain mustard	2 Tbsp
French mustard	1 tsp
Dry white wine	125ml
Water	3 Tbsp
Honey	1 tsp
Dried thyme	1 tsp
Single cream	3 Tbsp
New potatoes	10-12
Olive oil	1 Tbsp
Fresh herbs:	1 bunch, roughly chopped (basil, parsley, tarragon etc.)
Salt and pepper	



Put the potatoes, olive oil and fresh herbs in a large bowl and mix till the potatoes are coated. Put the potatoes into the bottom basket, put the chicken fillets into the second basket (above the potatoes) and put the lid on. Steam for about 25 minutes till cooked through.

---

### **CHICKEN IN LEMON AND GINGER MARINADE**

Chicken fillets	4, skinless
Fresh pasta	1 bag (Don't use dried pasta - must be fresh)
Butter	Small knob
Salt and black pepper	

#### **Marinade**

Fresh ginger	1 small piece, finely chopped
Fresh garlic	1 clove, finely sliced
Lemon	Juice and zest of half a lemon
Dry sherry	1 Tbsp
Oyster sauce	1 Tbsp
Light soy sauce	1 Tbsp
Light brown sugar	1 tsp

Mix the marinade ingredients in a bowl. Place the chicken fillets into the marinade, coat well, then cover the bowl and refrigerate for at least 30 minutes. Wrap the chicken fillets into individual foil parcels and put in the bottom basket. Put the fresh pasta (raw) in the second basket. Put the lid on and cook for 20-25 minutes. Toss the cooked pasta in a little butter and black pepper. Serve the chicken on top of the pasta.

---

## CHICKEN STUFFED WITH CREAMY PESTO

Chicken fillets	4, skinless
Fresh basil	1 packet or large bunch
Fresh Parmesan	50g
Cream cheese	100g, softened
Olive oil	1 Tbsp
Fresh garlic	2 cloves
Pine nuts	50g
Salt and pepper	

Process the basil, garlic, pine nuts, parmesan and olive oil till fairly smooth. Add the cream cheese and season. Slit the chicken breast to make pockets and fill with the creamy pesto filling. Secure with cocktail sticks, wrap into foil parcels and steam for 30-35 minutes. Spoon 'escaped' sauce over the fillets.

---

## STEAMED COD IN LIME AND BLACK PEPPER, WITH GARLIC & HERB VEGETABLE PARCEL

Cod fillets	4 (or use 1 cod loin)
Fresh lime	Juice and zest of 1 lime
Five spice seasoning	½ tsp
Olive oil	½ Tbsp
Sea salt and black pepper	

### Herby garlic vegetable parcel

Marrow	1 small cut into chunks
Red onion	1 sliced
Baby corn	4-5 sliced lengthways
Green beans	handful, trimmed
Baby potatoes	3-4 sliced thinly
Asparagus	3 sliced
Fresh garlic cloves	2-3 sliced thinly
Black pepper	

Mix the vegetables and garlic in a bowl and season with black pepper. Pour on to a large piece of kitchen foil, fold into a parcel and seal well. Put the fish, seasonings and oil in a

bowl and coat well. Place the vegetable parcel in the bottom basket, the fish in the basket above. Steam for about 15 minutes.

---

## **SALMON LOAF**

Tinned salmon	1 large (400g) can, or use Fresh Salmon
Eggs	2 medium size, lightly whisked
Milk	150ml
Spring onions	1 bunch finely chopped
Lemon juice	1 tsp
Worcester sauce	1 tsp
Dry mustard powder	½ tsp
Mayonnaise	1 Tbsp
Bread crumbs	From 2 slices wholemeal bread

Simply combine all ingredients into a large bowl and place into a dish (separate dish (glass/plastic) that will fit inside the steamer basket. Cover with foil and steam for 20-25 minutes. Serve warm or cold.

---

## **CHOCOLATE CAKE**

Butter	50g
Light vegetable oil	2 Tbsp
Golden syrup	2 Tbsp
Milk	50ml
Eggs	2 whisked
Castor sugar	125g
Baking chocolate	100g melted
Vanilla essence	2 tsp
Self raising flour	125g
Cocoa powder	35g
Boiling water	100ml

Dissolve the cocoa powder in the boiling water and set aside to cool. Meanwhile cream the butter and sugar, add half of the eggs then half of the flour. Repeat till they're finished. Add the other ingredients and mix well. Spoon into a dish (separate, glass or plastic), cover with foil and steam for 45 minutes.

---

## STICKY TOFFEE PUDDING

Walnuts	100g chopped
Butter	75g
Soft brown sugar	100g
Low fat fresh cream	60ml
Lemon juice	2 Tbsp
Eggs	2 beaten
Self raising flour	100g

Cream the butter and sugar. Stir in the cream. Add small amount of egg, then some flour and repeat. Add the lemon juice and walnuts and mix well. Spoon the mixture into a dish (glass/plastic that will fit into the steam basket). Cover with foil and steam for 40-45 minutes.

---

## FRUIT KEBABS WITH LEMON AND GINGER GLAZE

Wooden skewers	4-6
Pineapple	½ small, cubed
Bananas	2 thickly sliced
Kiwi fruit	2 cubed
Orange	1 peeled and cubed

### Glaze

Lemons	Juice of 2 and zest of 1 lemon
Honey	1 Tbsp
Lemon liqueur	1 Tbsp
Cornflour (maize)	2 tsp
Fresh ginger	Small piece, grated or finely sliced

Skewer the fruit by alternating it. Combine the glaze ingredients in a saucepan and cook on a medium heat for 2-3 minutes, till it thickens. Brush the kebabs with the glaze and fold loosely in foil. Place inside a steamer basket and cook for 5 minutes.

## SERVICING THE APPLIANCE

There are no user serviceable parts in this appliance. If the unit is not operating correctly, please check the following:

- You have followed the instructions correctly
- That the unit has been wired correctly and that the wall socket is switched on.
- That the mains power supply is ON.
- That the plug is firmly in the mains socket.

If the appliance still does not work after checking the above:

- Consult the retailer for possible repair or replacement. If the retailer fails to resolve the problem and you need to return the appliance, make sure that:

- The unit is packed carefully back into its original packaging.
- Proof of purchase is attached.
- A reason is provided for why it is being returned.

If the supply cord is damaged, it must be replaced by the manufacturer or an authorised service agent, in order to avoid any hazard. If service becomes necessary within the warranty period, the appliance should be returned to an approved Amalgamated Appliance (Pty) Ltd service centre. Servicing outside the warranty period is still available, but will, however, be chargeable.

## CHANGING THE PLUG

Should the need arise to change the fitted plug, follow the instructions below.


**This unit is designed to operate on 230V~240V current only. Connecting to other power sources may damage the appliance. Connect a three-pin plug as follows:**

The wires in this mains lead are coloured in accordance with the following code:

Green/Yellow = Earth

Blue = Neutral

Brown = Live



**PLEASE AFFIX YOUR PROOF OF PURCHASE/RECEIPT HERE**

**IN THE EVENT OF A CLAIM UNDER WARRANTY THIS RECEIPT MUST BE PRODUCED.**

**2 YEAR WARRANTY**

1 year retail  1 year extended  
warranty upon registration\*

visit [www.russellhobbs.co.za](http://www.russellhobbs.co.za)

**WARRANTY AND EXTENDED WARRANTY**

1. Home of Living Brands (Pty) Limited ("Home of Living Brands") warrants to the original purchaser of this product ("the customer") that this product will be free of defects in quality and workmanship which under normal personal, family or household use and purpose may manifest within a period of 1 (one) year from the date of purchase ("warranty period").
2. Home of Living Brands shall extend the warranty period for a further period of 1(one) year ("extended warranty period"), on condition that the purchaser registers the product on the website, within 12 months from the date of purchase of the product. The website address for registration is as follows: <http://russellhobbs.co.za/info-pages/warranty-info.aspx>. The extended warranty period only applies to products purchased on or after 1 October 2017.
3. Where the customer has purchased a product and it breaks, is defective or does not work properly for the intended purpose, the customer must notify the supplier from whom the customer bought the product ("the supplier") thereof within the warranty period or if applicable, the extended warranty period. Any claim in terms of this warranty must be supported by a proof of purchase. If proof of purchase is not available, then repair, and/or service charges may be payable by the customer to the supplier.
4. The faulty product must be taken to the supplier's service centre to exercise the warranty.
5. The supplier will refund, repair or exchange the product in terms of this warranty subject to legislative requirements. This warranty shall be valid only where the customer has not broken the product themselves, or used the product for something that it is not supposed to be used for. The warranty does not include and will not be construed to cover products damaged as a result of disaster, misuse, tamper, abuse or any unauthorised modification or repair of the product.
6. This warranty will extend only to the product provided at the date of the purchase and not to any expendables attached or installed by the customer.
7. If the customer requests that the supplier repairs the product and the product breaks or fails to work properly within 3 (three) months of the repair and not as a result of misuse, tampering or modification by or on behalf of the customer, then the supplier may replace the product or pay a refund to the customer, subject to the supplier's discretion.
8. The customer may be responsible for certain costs where products returned are not in the original packaging, or if the packaging is damaged. This will be deducted from any refund paid to the customer.

**HOME OF LIVING BRANDS (PTY) LTD (JOHANNESBURG)**

JOHANNESBURG  
CAPE TOWN  
DURBAN

TEL NO. (011) 490-9600  
TEL NO. (021) 552-5161  
TEL NO. (031) 303-1163

[www.homeoflivingbrands.com](http://www.homeoflivingbrands.com)  
[www.russellhobbs.co.za](http://www.russellhobbs.co.za)  
[www.facebook.com/RussellHobbs](https://www.facebook.com/RussellHobbs)