



Russell Hobbs®

INSTRUCTIONS AND WARRANTY



MODEL NO. RHFM-30

RUSSELL HOBBS FOOT MASSAGER

Congratulations on purchasing your new Russell Hobbs Foot Massager. Each unit is manufactured to ensure safety and reliability. Before using this appliance for the first time, please read the instruction manual carefully and keep it for future reference.

IMPORTANT SAFEGUARDS

When using any electrical appliance, basic safety precautions should always be followed including the following:

1. Please read the instructions carefully before using any appliance.
2. Always ensure that the voltage on the rating label corresponds to the mains voltage in your home.
3. Incorrect operation and improper use can damage the appliance and cause injury to the user.
4. The appliance is intended for household use only. Commercial use invalids the warranty and the supplier can not be held responsible for injury or damage caused when using the appliance for any other purpose than that intended.
5. Close supervision is required when any appliance is used near or by children or invalids.
6. Check the power cord and plug regularly for any damage. If the cord or the plug is damaged, it must be replaced by the manufacturer or a qualified person in order to avoid an electrical hazard.
7. Do not use the foot massager if it has been dropped or damaged in any way. In case of damage, take the unit in for examination and/or repair by an authorised service agent
8. To reduce the risk of electric shock, do not immerse or expose the motor assembly, plug or the power cord to water or any other liquid.
9. Never immerse the unit in water or any other liquid for cleaning purposes.
10. Remove the plug from the socket by gripping the plug. Do not pull on the cord to disconnect the appliance from the mains. Always unplug the unit when not in use, before cleaning or when adding or removing parts.
11. The use of accessory attachments that are not recommended or supplied by the manufacturer may result in injuries, fire or electric shock.
12. Do not allow the cord to touch hot surfaces and do not place on or near a hot gas or electric burner or in a heated oven.
13. If it is necessary to use an extension lead, ensure that the lead is suited to the power consumption of the appliance to avoid overheating of the extension cord, appliance or plug point. Do not place the extension cord in a position where it can be pulled on by children or animals or tripped over.
14. This appliance is not suitable for outdoor use. Do not use this appliance for anything other than its intended use.
15. DO NOT carry the appliance by the power cord.

16. DO NOT leave this appliance unattended during use. Always unplug the unit when not in use or before cleaning.
17. Always operate the appliance on a smooth, even, stable surface. Do not place the unit on a hot surface.
18. Ensure that the switch is in the "0"/ Off position after each use.
19. The manufacturer does not accept responsibility for any damage or injury caused by improper or incorrect use, or for repairs carried out by unauthorised personnel.
20. In case of technical problems, switch off the machine and do not attempt to repair it yourself. Return the appliance to an authorised service facility for examination, adjustment or repair. Always insist on the use of original spare parts. Failure to comply with the above mentioned pre-cautions and instructions, could affect the safe operation of this machine.

SPECIAL WARNING:


Important: Please consult your doctor if any of the following conditions are applicable:

- High blood pressure
- Varicose veins
- Diabetes
- Pacemaker
- Pregnancy

Do not use the foot spa in the following circumstances:

- Tuberculosis
 - Haemorrhages
 - Diabetes
 - Open flesh wounds
 - Undetermined calf or joint pain
 - Benign or malignant tumours
 - Inflammation of the skin
 - Phlebitis and thrombosis
 - Bruises
-
- Always check the temperature of the water before putting your feet into the foot spa.
 - DO NOT stand in the unit. Sit down in a comfortable chair and place your feet into the basin.
 - Always unplug the unit when not in use, when filling with water, emptying, cleaning or moving the appliance.
 - Make sure that your hands are dry when operating the control dial or removing the plug.

PARTS DIAGRAM



OPERATING INSTRUCTIONS

Remove the Russell Hobbs Foot Massager from the packaging.

Remember to set a towel nearby to dry feet afterwards.


1. Make sure the dial is on the "0" or OFF position.
2. Fill the Foot Massager with the desired temperature warm water. The unit will maintain this temperature for the duration of use.

Important:

Ensure the unit is unplugged before filling with water. Do not overfill the basin of the foot spa over the 'MAX' level (see 'water level indicator' location on Parts Diagram).

3. Plug in the appliance at the mains socket.
4. Sit down in a comfortable chair and place your feet in the foot spa.
5. Select the vibrating massage function by using the dial on the control panel, as follows:
 - a. Position 0: Off
 - b. Position 1: Bubble + Massage + Infrared
This setting provides a comfortable vibration massage. The stimu-nodes act as fingers that provide the soles of your feet with an effective massage while the air jets offers a relaxing bubble bath. The infrared heat provides concentrated heat for tired and aching feet.
 - c. Position 2: Water heat-function + Aeration
With this setting the water temperature will be maintained at a comfortable temperature. By adding a few drops of aromatic oil on the cotton pad inside the aroma diffuser you

can indulge in a personal aroma therapy treatment. The aroma diffuser also serves as a nail polish dryer in case of a pedicure treatment.



d. Position 3: Massage + Infrared

This setting provides a comfortable vibration massage. The stimu-nodes act as fingers that provide the soles of your feet with an effective massage while the infrared heat provides concentrated heat for tired and aching feet.

6. Detachable acupressure massage rollers can be fitted to the surface of the footspa to deliver a targeted massage to the arches and soles of the feet.
7. Upon completion of the massage, switch the unit OFF at the dial and unplug from mains.
8. Dry your feet
9. Empty the container into the basin/bath by tilting the unit and allowing water to flow out over the drain spout
10. Never allow the water to run over the control dial.

CLEANING AND MAINTENANCE

- This appliance is for household use only and is not user-serviceable.
- Do not open or change any parts yourself. Please refer to a qualified electrical service department or return to the supplier if servicing is necessary.
- Always remember to unplug the unit from the electrical outlet and allow it to cool down before cleaning.
- To clean the appliance, simply wipe down surfaces with a damp cloth and a mild detergent solution, then rinse and dry thoroughly before packing away.
- Do not use bleach or other abrasive substance or solvents to clean your appliance as it can be damaging to the finish.
- Never immerse the entire unit in water or in any other liquids.

STORING THE APPLIANCE

- Unplug the unit from the wall outlet and clean as instructed above. Ensure that all parts are dry before storing.
- Store the foot spa in its box or in a clean, dry place.
- Never store the appliance while it is still wet or dirty.
- Never wrap the power cord around the appliance.


CHANGING THE PLUG

The unit is supplied with a 2 pin VDE plug, and is not earthed.

If you wish to change the plug to a 3 pin, round pin plug, please connect as follows:

The wires in this mains lead are coloured in accordance with the following code:

No earth wire Blue = Neutral Brown = Live



PLEASE NOTE: THIS IS A CLASS II PRODUCT AND DOES NOT NEED TO BE EARTHED

SERVICING THE APPLIANCE

There are no user serviceable parts in this appliance. If the unit is not operating correctly, please check the following:

- You have followed the instructions correctly
- That the unit has been wired correctly and that the wall socket is switched on.
- That the mains power supply is ON.
- That the plug is firmly in the mains socket.

If the appliance still does not work after checking the above:

- Consult the retailer for possible repair or replacement. If the retailer fails to resolve the problem and you need to return the appliance, make sure that:

- The unit is packed carefully back into its original packaging.
- Proof of purchase is attached.
- A reason is provided for why it is being returned.

If the supply cord is damaged, it must be replaced by the manufacturer or an authorised service agent, in order to avoid any hazard. If service becomes necessary within the warranty period, the appliance should be returned to an approved Amalgamated Appliance (Pty) Ltd service centre. Servicing outside the warranty period is still available, but will, however, be chargeable.

**PLEASE AFFIX YOUR PROOF OF PURCHASE/RECEIPT HERE
IN THE EVENT OF A CLAIM UNDER WARRANTY THIS RECEIPT MUST BE
PRODUCED.**

WARRANTY

Amalgamated Appliances (Pty) Limited (“the Supplier”) warrants to the original purchaser of this product (“the Customer”) that this product will be free of defects in material and workmanship which under normal, personal, family or household purpose manifest themselves within a period of 365 days from the date of purchase or in respect of commercial or professional purposes, manifest themselves within a period of 90 days from the date of purchase. Any claim in terms of the warranty must be supported by a proof of purchase. If such proof is not available, then notwithstanding anything to the contrary herein, the Supplier’s normal charge for service and/or spares will be payable by the Customer upon collection of the repaired product. If a claim is made in terms of the aforesaid warranty within the first 7 days from the date of purchase, the faulty product will be exchanged (provided that the product is in its original packaging with all accessories). Failing return of the product within 7 days, the Supplier’s liability shall be limited on return to the Supplier of the product or parts thereof, to the replacement or repair (in the sole discretion of the Supplier, or its duly authorised service dealer) of the product to eliminate any defect in workmanship or materials found to be due exclusively to any acts or omissions on the parts of the Suppliers, of which defects the Supplier shall have been notified in writing by the Customer within the aforesaid warranty period. The warranty provided herein and the obligations of the Supplier as aforesaid are in lieu of, and the Customer waives, all other warranties, guarantees, conditions or liabilities, express or implied, arising by law or otherwise, including without limitation, any obligation of the Supplier in respect of any injury, loss or damage (direct, indirect or consequential) arising out of the use of, or inability to use, this product and whether or not occasioned by the Supplier’s negligence (gross or otherwise) or any act or omission on its part. The warranty does not include and will not be construed to cover products damaged as a result of disaster, misuse, abuse or any non-authorized modification of the product. The warranty does not include replacement of light bulbs, heater bars, paper bags or any glass, plastic bowl or jug or other expendables. During the warranty period the product should be taken to a service centre of the Supplier or one of its duly authorised service agents. The Supplier neither assumes nor authorises any other person to assume for it, any additional liability in connection with the sale or servicing of its products.

AMALGAMATED APPLIANCES (PTY) LTD

JOHANNESBURG
29 HERONMERE ROAD
P O BOX 39186
BOOYSENS, JOHANNESBURG, 2016

TEL NO. (011) 490-9000

CAPE TOWN

TEL NO. (021) 535-0603

DURBAN

TEL NO. (031) 792-6000

WIN PRIZES ONLINE – www.russellhobbs.co.za